

LOMANCO 750 & 750G ROOF VENT INSTALLATION INSTRUCTIONS

IMPORTANT!

- Read These Instructions Carefully Before Starting Installation.
- Installation of Lomanco Roof Vents should comply with all local codes and standards.
- **WARNING!** Sharp edges are exposed during installation. Use gloves and other appropriate safety equipment to avoid injury.

INSTALLATION:

1. Vents should be evenly spaced on the rear slope of the roof.
2. Center the vent hole between rafters and roughly 24" (36" Max.) down from the ridge line to keep the top of the roof vent below the ridge line. Mark this position.
3. Using marked position as center point, scribe a circle that is 8" in diameter. Drill a starter hole inside the scribe lines.
4. Starting in the drill hole cut vent hole.
5. Carefully remove roofing nails from top row of shingles so the flashing of the roof vent will slide under shingles.
6. Lomanco, Inc. recommends applying roofing cement around the edge of the hole.
7. Carefully slide base of vent under shingles with arrow pointing up. Make sure throat of vent is centered over vent hole. Fasten the base to roof decking with roofing nails, keeping

heads of nails under shingles where possible. Seven nails are required for each vent and should be located as shown below.

8. Lomanco, Inc, recommends finishing mounting by sealing all seams and nails with roofing cement. Also use roofing cement to fasten down loose edges of shingles. Note: On 750 Series Vents **DO NOT CAULK** gap, between sides and base or back and base.

"ITEMS NEEDED FOR INSTALLATION"

KEYHOLE SAW OR SABER SAW

UTILITY KNIFE

DRILL WITH ½" BIT

HAMMER AND ROOFING NAILS

TAPE MEASURE

ROOFING CEMENT

COMPASS OR STRING

